


ASSEMBLY INSTRUCTIONS

COMPLETE SUSPENSION KIT




INSTALLATION HARDWARE




BRASS T NUT



TOP CAP
(4M CABLE INCLUDED)



EZO CLAMP



**SUSPENSION
TRACK(S)**



**LOWER SUSPENSION
HOUSING***
(4M CABLE INCLUDED)

*Images reflect typical hardware options. Please refer to packing list for items & quantities specific to your order

Thank you for your order!



For questions or concerns regarding your order or installation, please contact customer service at 1-844-441-1122 or via email at sales@ayrsonics.com (Canada) or info@usa.ayrsonics.com (USA).

ASSEMBLY INSTRUCTIONS

WORK ZONE DIVIDER

COMPLETE SUSPENSION KIT

- 1** Locate available pick points on ceiling and floor* in relation to WZD suspension locations (Recommended 6-12" inset).
- 2** Drill pilot holes in top rail where mechanical fasteners will be used to mount the suspension track .
- 3** Install the suspension track on the ceiling and floor* using substrate appropriate fasteners (not included).
- 4** Insert brass T-nut into suspension track and rotate approximately 30 degrees.
- 5** Thread top cap and bottom cap onto T-nut and hand tighten.
- 6** Mark and drill pilot holes for Ezo Clamp on WZD.
- 7** Attach Ezo Clamp to the WZD in predetermined location, using the set screw supplied.
- 8** Raise unit to desired height by depressing top nozzle and threading cable through from top (Ezo Clamp will lock when nozzle is released) If lower hardware is spec'd, complete top and repeat steps 6-10 for bottom hardware.
- 9** Hand tighten top nozzle to lock cable in place.
- 10** Trim excess cable.



RECOMMENDED TOOLS

Drill - Level - Laser - Tape Measure - Allen Key

Thank you for your order!

For questions or concerns regarding your order or installation, please contact customer service at 1-844-441-1122 or via email at sales@ayrsonics.com (Canada) or info@usa.ayrsonics.com (USA).